

Document made available under the Patent Cooperation Treaty (PCT)

International application number: PCT/GB05/000965

International filing date: 11 March 2005 (11.03.2005)

Document type: Certified copy of priority document

Document details: Country/Office: GB
Number: 0406110.7
Filing date: 18 March 2004 (18.03.2004)

Date of receipt at the International Bureau: 21 April 2005 (21.04.2005)

Remark: Priority document submitted or transmitted to the International Bureau in compliance with Rule 17.1(a) or (b)



World Intellectual Property Organization (WIPO) - Geneva, Switzerland
Organisation Mondiale de la Propriété Intellectuelle (OMPI) - Genève, Suisse



PCT/GB2005/000965



INVESTOR IN PEOPLE


The Patent Office
Concept House
Cardiff Road
Newport
South Wales
NP10 8QQ

I, the undersigned, being an officer duly authorised in accordance with Section 74(1) and (4) of the Deregulation & Contracting Out Act 1994, to sign and issue certificates on behalf of the Comptroller-General, hereby certify that annexed hereto is a true copy of the documents as originally filed in connection with the patent application identified therein.

In accordance with the Patents (Companies Re-registration) Rules 1982, if a company named in this certificate and any accompanying documents has re-registered under the Companies Act 1980 with the same name as that with which it was registered immediately before re-registration save for the substitution as, or inclusion as, the last part of the name of the words "public limited company" or their equivalents in Welsh, references to the name of the company in this certificate and any accompanying documents shall be treated as references to the name with which it is so re-registered.

In accordance with the rules, the words "public limited company" may be replaced by p.l.c., plc, P.L.C. or PLC.

Re-registration under the Companies Act does not constitute a new legal entity but merely subjects the company to certain additional company law rules.



Signed

Dated 5 April 2005



59186800

Patents Form 1/77


Patents Act 1977
(Rule 16)



1/77

Request for grant of a patent

(See the notes on the back of this form. You can also get an explanatory leaflet from the Patent Office to help you fill in this form.)



The Patent Office

Cardiff Road
Newport
South Wales
NP10 8QQ

1. Your reference

620GB

2. Patent application number
(The Patent Office will fill in this part)

0406110.7

18 MAR 2004

3. Full name, address and postcode of the or of each applicant (underline all surnames)

Renishaw plc
New Mills
Wotton-under-Edge
Gloucestershire, GL12 8JR

Patents ADP number (if you know it)

2691002 ✓

If the applicant is a corporate body, give the country/state of its incorporation

4. Title of the invention

Scanning an Object

5. Name of your agent (if you have one)

Emma Leland et al

"Address for service" in the United Kingdom to which all correspondence should be sent (including the postcode)

Renishaw plc
Patent Department
New Mills
Wotton-under-Edge
Gloucestershire, GL12 8JR

Patents ADP number (if you know it)

2691003

6. If you are declaring priority from one or more earlier patent applications, give the country and the date of filing of the or of each of these earlier applications and (if you know it) the or each application number

Country	Priority application number (if you know it)	Date of filing (day / month / year)
---------	--	-------------------------------------

7. If this application is divided or otherwise derived from an earlier UK application, give the number and the filing date of the earlier application

Number of earlier application	Date of filing (day / month / year)
-------------------------------	-------------------------------------

8. Is a statement of inventorship and of right to grant of a patent required in support of this request? (Answer 'Yes' if)

Yes


- a) any applicant named in part 3 is not an inventor, or
 - b) there is an inventor who is not named as an applicant, or
 - c) any named applicant is a corporate body.
- See note (ii))

Patents Form 1/77

Patents Form 1/77

9. Enter the number of sheets for any of the following items you are filing with this form. Do not count copies of the same document

Continuation sheets of this form	0
Description	9
Claim(s)	0
Abstract	0
Drawing(s)	3



10. If you are also filing any of the following, state how many against each item.

Priority documents	0
Translations of priority documents	0
Statement of Invention and right to grant of a patent (Patents Form 7/77)	0
Request for preliminary examination and search (Patents Form 9/77)	0
Request for substantive examination (Patents Form 10/77)	0
Any other documents (please specify)	0

11.

I/We request the grant of a patent on the basis of this application.

Signature E. Helen Date 18.03.04
AGENT FOR THE APPLICANT

12. Name and daytime telephone number of person to contact in the United Kingdom

A ILES 01453 524524

Warning

After an application for a patent has been filed, the Comptroller of the Patent Office will consider whether publication or communication of the invention should be prohibited or restricted under Section 22 of the Patents Act 1977. You will be informed if it is necessary to prohibit or restrict your invention in this way. Furthermore, if you live in the United Kingdom, Section 23 of the Patents Act 1977 stops you from applying for a patent abroad without first getting written permission from the Patent Office unless an application has been filed at least 6 weeks beforehand in the United Kingdom for a patent for the same invention and either no direction prohibiting publication or communication has been given, or any such direction has been revoked.

Notes

- If you need help to fill in this form or you have any questions, please contact the Patent Office on 08459 500505.
- Write your answers in capital letters using black ink or you may type them.
- If there is not enough space for all the relevant details on any part of this form, please continue on a separate sheet of paper and write "see continuation sheet" in the relevant part(s). Any continuation sheet should be attached to this form.
- If you have answered 'Yes' Patents Form 7/77 will need to be filed.
- Once you have filled in the form you must remember to sign and date it.
- For details of the fee and ways to pay please contact the Patent Office.

SCANNING AN OBJECT

The present invention relates to a method and apparatus for scanning an object using a surface measurement probe mounted on a coordinate positioning apparatus. Coordinate positioning apparatus includes, for example, coordinate measuring machines (CMM), machine tools, manual coordinate measuring arms, scanning machines and inspection robots.

10

In particular, the invention relates to a method and apparatus for scanning teeth and dental parts.

It is known to measure an object by using a surface measurement probe mounted on a coordinate positioning apparatus, for an example coordinate measuring machines. The measurement data of the surface of the object thus determined provides a 3D map of the surface of the object.

20

A first known method of scanning the surface of an object comprises moving the surface measurement probe along a single direction, for example the x axis, and following the surface of the object along that axis with the probe. This scan provides measurement data along a single plane. To obtain measurement data in the adjacent plane the surface measurement probe must be stopped and reversed to repeat the scan in the next plane and in successive planes, giving a raster scan over the whole surface. This method has the disadvantage that it is slow due to the requirement to stop and reverse the surface measurement probe at the end of each plane.

30

Another method for scanning the surface of an object comprises moving the surface measurement probe around the surface of the object in the xy plane and repeating the step for adjacent slices of the object translated in the z direction. This method is also slow and has the further disadvantage that if the top surface is horizontal it cannot be measured using the same scan profile.

Our earlier International Patent Application No. WO03/046412 discloses a method of scanning a sample in which the sample is positioned on a mount which is provided with a generally helical screw-thread so that the mount and the sample rotate in a helical path. A probe is positioned at a suitable point on the surface of the sample so that on rotation of the mount, a spiral scan is produced of the sample.

This method is limited due to its mechanical nature as it requires a particular mechanical set-up and, for example, the thread pitch cannot be adjusted.

The present invention provides a method for scanning an object with a surface measurement probe comprising the steps of:

- defining a first axis of the object;
- defining a second axis, said second axis being at an angle to the first axis;
- rotating the second axis for an at least part revolution about the first axis and translating the second axis in a direction parallel to the first axis;
- moving the surface measurement probe along a scan profile mapped out by movement of the second axis such that the probe follows a spiral profile around the

object for an at least part revolution.

This method has the advantage that the spiral profile provides a continuous and fast scan.

5

The method also has the advantage that single scan profile enable measurement of both the sides and top of the object. This is particularly important for objects such as teeth in which information is required from both the top and side surfaces.

10

Furthermore, this method may be carried out on any coordinate positioning apparatus as no mechanical parts are required to form the spiral scan profile.

15

As the spiral scan profile is not defined by mechanical parts, the profile dimensions can easily be adjusted, such as pitch of spiral and angle of the second axis.

20

The surface measurement probe may comprise a contact probe having a deflectable stylus. In this case the method may comprise a further step of moving the probe parallel to the second axis to control probe deflection.

25

The method may comprise the step of maintaining the probe on the second axis by movement of the probe perpendicular to said second axis.

30

The surface measurement probe may comprise a non-contact probe, for example an optical, capacitance or inductance probe.

Preferably the second axis intersects the surface of

the object to be measured.

Preferred embodiments of the invention will now be described by way of example with reference to the accompanying drawings, wherein:

Fig 1 is a perspective view of the object to be scanned;

Fig 2 illustrates the spiral scan profile;

Fig 3 illustrates the scan profile for a series of half revolutions of the second axis;

Fig 4 illustrates measurement of a surface having an undercut; and

Fig 5 illustrates a plan view of the scan profile.

As illustrated in Fig 1 an object 10, to be measured e.g. a tooth, is mounted 12 on a mount of the coordinate positioning apparatus. An axis of rotation 14 of the object is specified by the user. This may for example be the z axis of the part coordinate system of the object. The rotational axis 14 may be defined with respect to the mount 12 by the object 10 being mechanically aligned to this axis when mounted on the mount. A second axis 16 is defined which is at an angle ϕ to the rotation axis 14 and which intersects the surface of the object 10. The second axis 16 may be at any angle to the rotation axis 14 (but not parallel) and Fig 1 shows the second axis being at 45° . The second axis 16 is rotated about the axis of rotation 14 and is translated parallel to the axis of rotation 14 thus creating a spiral profile. Fig 2 illustrates the spiral profile 18 created by this movement of the second axis about the axis of rotation. As described in more detail below, a probe is moved along the spiral profile created by the movement of the

second axis to scan the object along this spiral profile. Fig 3 illustrates the scan profile 20 created when the second axis is rotated a part revolution about the axis of rotation and translated parallel to the axis of rotation. This scan profile is suitable for use with a probe having a T stylus 22 as illustrated. A surface measurement probe 24 is mounted on the coordinate positioning apparatus for relative movement with respect to the mount 12. The probe 24 has a deflectable stylus 26 with a surface contacting tip 28.

The probe 24 follows the spiral profile created by movement of the second axis 16 and thus scans the object 10 by following a spiral profile.

Movement of the probe is controlled by an algorithm having two components. The first component keeps the probe on the second axis. This is accomplished by determining the position of the stylus tip of the probe, determining the nearest position on the second axis to the stylus tip and moving the probe in a direction perpendicular to the second axis back onto the second axis.

The second component of the algorithm controls the probe deflection. In this case the probe is moved parallel to the second axis to provide the desired probe deflection.

Both of the algorithm components are calculated as position demands.

In the present example, the second axis has an angle of 45°. This is convenient for most applications because

it will intersect with both the side and top surfaces, it enables both of these surfaces to be scanned in a single scan. This is particularly important where measurement of the top surface is important, for example for teeth.

An advantage of this method is that the angle of the second axis may be varied. Fig 4 illustrates an object 30 having an undercut 32. In the embodiment above the second axis was angled at 45° to the axis of rotation (shown by dashed line 34). This allows measurement of an undercut at an angle of 45° or below. An undercut having an angle of greater than 45° is not intersected by the second axis angled at 45° and thus cannot be scanned using this profile. However if the angle of the second axis is changed, for example to 90° to the axis of rotation, this new second axis 36 now intersects the undercut which can be scanned using the spiral profile. The angle of the second axis can be changed during the scan. Thus objects with sharp undercuts can still be scanned in a single scan profile which has the advantage of enabling a fast scan. This is particularly relevant for scanning objects such as teeth which have undercuts.

The angle of the second axis may be changed automatically using stylus deflection data to determine when to change the angle. For example, referring to fig 4, the object 30 may be scanned upwards from at or near the bottom of the object using a horizontal second axis 36. When the stylus tip reaches the corner 38 of the undercut 32, the stylus will be deflected in -Z and the angle of the second axis will in response change automatically to 45° . Alternatively, the angle of the

The algorithms used to control the position of the
5 probe will now be described with reference to Fig 5.

10 $\theta = \Omega T$

15 In a next step, the rotation matrix is created:

Where "Rotation" is the rotation matrix.

$$\text{Direction:} = \text{Rotation} \begin{bmatrix} \frac{1}{\sqrt{2}} \\ 0 \\ \frac{1}{\sqrt{2}} \end{bmatrix}$$

25 The origin translation in z due to the thread pitch is
then calculated.

$$\text{Origin:} = \begin{bmatrix} 0 \\ 0 \\ \frac{\theta}{2\pi} \text{Pitch} \end{bmatrix}$$

Where "Origin" is the origin translation in z and
 "Pitch" is the thread pitch.

5

Next the scan position demand is calculated. This is
 the nearest point on the second axis to the current
 machine position, where "machine" is the position of
 the centre of the stylus ball when there is no
 10 deflection.

ScanPositionDemand:= [(Machine - Origin).Direction].
 Direction + Origin .

15 The probe deflection error is calculated from:

Deflection error:= |Probe deflection| - Nominal
 deflection

20 Where "Probe deflection" is the actual probe deflection
 and "Nominal deflection" is the desired probe
 deflection.

The probe deflection error is used to calculate the
 25 deflection control vector:

ProbePositionDemand:= DefError.Direction

Where "DefError" is the probe deflection error and
 30 "direction" is the direction parallel to the second
 axis along which the probe is moved.

The position demand vector can thus be determined from the deflection control vector and the scan position demand vector:

- 5 $\text{PositionDemand} := \text{ScanPositionDemand} + \text{ProbePositionDemand}$

The velocity demand can thus be created:



- 10 $\text{VelocityDemand} := \frac{\text{PositionDemand} - \text{Machine}}{\delta t}$

Although the above description describes the use of a contact probe, the method is also suitable using a non-contact probe e.g. an optical, capacitance or

- 15 inductance probe. If a 1-D non-contact probe is used, the probe will need to be rotated to keep it directed at the surface of the object as the probe follows the spiral profile. However using this method, the direction in which the probe must face is known.

- 20 Offset of the non-contact probe may be adjusted by moving the probe parallel to the second axis in a similar manner to how probe deflection is adjusted for a contact probe.










Fig 3




Fig 4



3/3




Fig 5

GB2005/000968.

GB0406110.7

